









Important: Read All Instructions Prior to Installation

Function introduction



Scene button, press and hold down to save a scene, click



Rotary switches for setting start DALI address number (0-63), the number equals to tens position plus units position


Product Data

| Output | DALI signal |
|-----------------------|--------------|
| Power Supply | 12-24VDC |
| Operation Current | 200mA |
| Operating temperature | 0-40°C |
| Relative humidity | 8% to 80% |
| Dimensions | 86x86x29.1mm |
| Waterproof grade | lp20 |

- · Touch sensitive.
- · Glass interface(white & black).
- Comply to DALI standard protocol IEC 62386-102, IEC 62386-207 and in compliance with DALI products from other international incorporation
- · 4 light zones are available for switch and dimming control, each zone can control 1 DALI address.
- Enable to set start DALI address number (0-63) to be controlled by the 4 zones by rotary switches on the back.
- · Enable to save 4 scenes

Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.



Operation

Set start DALI address number to be controlled by 4 zones by rotary switches on the back, each zone controls 1 DALI address:

Set the number as X (0-63):

Zone number 1 will control DALI address X,

Zone number 2 will control DALI address X+1,

Zone number 3 will control DALI address X+2,

Zone number 4 will control DALI address X+3,

Note: if X is set as 63, zone 1 will control DALI address 63, zone 2 will control address 00, zone 3 will control address 01, zone 4 will control address 02.

Installation

